SpatKeyboard 26

velocity control of
the envelope Attack
and Release times

mono After Touch control
of the volume

envelope parameters
for the selected zone

volume of the selected zone

selection of the outputs / speakers to which
the sound is sended for the selected zone
first line = left input
second line = right input

trigger indicator

selects the Note Number
which activates this zone

global control for the envelopes times
of all zones, can be controlled by the
MIDI controller n°1 (Modulation Wheel)

selects the zone to be edited

MIDI Learn function : click on Learn, move an object,
move a MIDI Controller : it's done.
If you use several SpatKeyboard 212 at the same time,
you must select a different ID number for each of them.

note : all the zones can be activated at the same time